

YEAR 2013 SPEEDPLAY ROAD SHOE COMPATIBILITY GUIDE**

NOTE: VARIATIONS IN SHOE SOLE CURVATURES MAY REQUIRE SNAP SHIMS OTHER THAN THOSE RECOMMENDED BELOW. PLEASE VISIT OUR WEBSITE AT WWW.SPEEDPLAY.COM TO SEE OUR CLEAT INSTALLATION VIDEO UNDER TECH SUPPORT / ULTIMATE FIT TECHNICAL VIDEOS.

2013 MODEL SHOES COMPATIBLE WITH FACTORY-INSTALLED 1-F AND 1-R SNAP SHIMS

Bont 3 hole // Bontrager Nylon // Bontrager Silver Series Carbon // Exustar // Fizik // FLR // Gaerne // Giro Carbon // Lake // Mavic // Northwave // Scott Carbon // Serfas-Nylon // Sidi Vent Carbon // Specialized // Suplest

SNAP SHIMS REQUIRED FOR NON-STANDARD 2013 MODEL SHOES AND PRIOR YEAR MODEL SHOES

Answer	2009 & earlier	Use 1-F & 1-R Snap-Shims.
Bont - 3 hole	2012 & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Bontrager - Carbon	2012 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Carnac	2011 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Carnac Insert-type	2011 & earlier	Omit base plate. Use Carnac-supplied UCS3 insert. Requires Speedplay 4x15-8 Cleat Fastening Screws (Part #13015).
CHAIN - Carbon	2012 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
CHAIN - Nylon	2012 & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Diadora - Carbon, Jet Racer	Current year & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Diadora - Nylon	Current year & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Diadora Alu	Current year & earlier	Call Speedplay for installation instructions. 1-800-468-6694.
Diadora Multiped	Current year & earlier	Omit base plate. Use Diadora-supplied Time/Speedplay insert.
DMT	2010 - 2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
DMT	2009 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
DMT - Insert-type	Current year & earlier	* Remove Snap-Shims from base plate. Sole must be modified to allow rearward cleat adjustment. See photo at www.speedplay.com .
Duegi	2008 & earlier	Use 1-F & 1-R Snap-Shims.
Exustar	2012 & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Giro - Nylon	2012 - 2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Kuips	2011 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Lake Anatomic Carbon & Nylon	2012	Use 1-F & 1-R Snap-Shims.
Lake Carbon & Nylon	2011 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Look	2007 & earlier	Use 1-F & 1-R Snap-Shims.
Louis Garneau - Carbon Compo / Carbon X-Vent / Compo X-Vent / Ergo Air Nylon / HM X-Lite	2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Louis Garneau	2007 - 2012	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Louis Garneau Carbon Ergo	2012 & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Luck	2009 & earlier	Use 1-F & 1-R Snap-Shims.
Nalini Carbon	2009 - 2011	Use 1-F & 1-R Snap-Shims.
Nalini	2008	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Nalini	2006 - 2007	Call Speedplay for installation instructions. 1-800-468-6694.
Nalini CARBONALINI sole	2009	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Nike	2009 & earlier	Use 1-F & 1-R Snap-Shims.
Northwave Speedplay	2012 - 2013	Requires Northwave-supplied kit: NW Speedplay adaptor.
Northwave Centurion, Mirage, Solo, Diana Road, Husky	Current year & earlier	Omit base plate. Use Northwave-supplied Time/Speedplay insert. Requires 4x13-8 Cleat Fastening Screws (Part #13295) available from Speedplay.
Pearl Izumi	2012 - 2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Pearl Izumi	2011	Use 1-F & 1-R Snap-Shims.
Pearl Izumi	2010 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Pearl Izumi I Beam Sole	2010 & earlier	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Scott - Carbon	2010 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Scott - Nylon	2011 - 2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Scott - Nylon	2010 & earlier	Use 1-F & 1-R Snap-Shims.
Serfas - Carbon	2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Shimano	2013 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
SIDI - Carbon Comp / Carbon Millenium III / Vent Carbon	2012 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Sidi Carbon Lite & Sidi Glass Fiber Comp	2012	Use 1-F & 1-R Snap-Shims.
Sidi - Eleven / Millenium III	2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
SixSixOne	2008 & earlier	Use 1-F & 1-R Snap-Shims.
Specialized (FACT Soles & Nylon/Glass Reinforced Soles)	2010 - 2012	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Specialized Full Carbon Pro Models	2009	Use 1-F & 1-R Snap-Shims.
Specialized NON Carbon Models	2009	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Specialized	2007 - 2008	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Time	2009 - 2012	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Time	2008 & 2006	Use 1-F & 1-R Snap-Shims. May require "Extra Shim" under cleat-mounting screw of each base plate.
Vittoria	2011 - 2013	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Vittoria	2009 & earlier	Use 1-F & 1-R Snap-Shims.
Wellgo	2010 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.
Xpedo	2012 & earlier	* Remove 1-F & 1-R Snap-Shims. Install 4-F & 4-R Snap-Shims.

*** Ensure the factory-installed cleat nuts remain in the base plate.**

Shoes with 4-hole cleat pattern (Speedplay Base Plate not used).

adidas / Bont / DMT / Lake / Rocket 7 / Sidi	Current year & earlier	Omit base plate. See note below regarding 4-Hole Carbon Fiber Soles.
Northwave Evolution	Current year & earlier	Omit base plate. Requires Speedplay 4x15-8 screws (Part #13015). See note below regarding 4-Hole Carbon Fiber Soles.

INCOMPATIBLE SHOES

adidas	2007 - 2008		Nalini Nylon	2011 - 2013	
DMT Mag Force & Mag Light	2008		Northwave Carbonio	Current year & earlier	
Exus	Current year & earlier		Scott Full Carbon Power Transfer Sole	2009	
Lake CX 401	2010 & earlier		Scott - Road Ltd.	Current year & earlier	
Lake 115 & 125	Current year & earlier		Shimano WITHOUT 3-Hole (Look) pattern	Current year & earlier	
Mavic	2009 & earlier		Shimano Carbon Fiber	2004 & earlier	X Series incompatible
Nalini Carbon	2012 - 2013		All MTB shoes and road shoes with MTB-type lugged soles	Current year & earlier	

4-Hole Carbon Fiber Soles: Must use the Carbon Sole Protector Kit (Part #13290), sold separately and available from Speedplay, to prevent contact between the pedal body and the carbon-fiber sole. Carbon fiber is a poor wear surface and unless a wear protector is used, damage to both the pedals and shoes will result.

WARNING! - Do not use the Snap-Shim Cleat mounting screws with any previous models of Speedplay X cleats including the Slim Line Cleat. The Snap-Shim Cleat mounting screw heads are too small and may pull through the older base plates. This may cause the cleat to pull off the shoe causing a fall that may result in severe injury.

**** See detailed photos of select sole mountings and the latest updates for shoe compatibility at www.speedplay.com or call the Speedplay Tech Department at 1-800-468-6694 (PST).**