


Battery Mount

BM-EN801-A

BM-EN801-B



ITEM NO.	SHIMANO CODE NO.	DESCRIPTION	INTERCHANGE-ABILITY		
			A		
1	Y7GS00090	Bracket fixing screw (M6 x 10)	A		
2	Y7K498010	Upper mount unit	A		
3	Y7GS00100	Upper base fixing screw A (M5 x 18)	A		
4	Y7GS00110	Upper base fixing screw B (M4 x 8)	A		
5	Y7GS98020	Spring unit and fixing screw (M3 x 4)	A		
6	Y7GS00230	Stopper screw (M4 x 5)	A		
7	Y7GS00200	Lower mount rubber L	A		
8	Y7GS00190	Lower mount rubber R	A		
9	Y7GS00350	Lower bracket fixing screw (M6 x 12)	A		
10	Y7GS00220	Lower bracket rubber B	A		
11	Y7GS00210	Lower bracket rubber A	A		
12	Y13000050	TL-BME04 Battery mount setting tool	A		
	Y13000070	TL-BME05 Battery mount setting tool	A		
13	Y7K39801T	Lever			

A: Same parts.

B: Parts are usable, but differ in materials, appearance, finish, size, etc.

Absence of mark indicates non-interchangeability.

Specifications are subject to change without notice.

Nov.-2022-4980

© Shimano Inc. I

SHIMANO