

Lime 374



PRODUCT TYPE	Acidic descaler
APPLICATION	Lime 374 is used for descaling of coffee machines, washing machines and dishwashers.
PROPERTIES	Lime 374 effectively removes lime residues. Do not use on untreated aluminum, light metal alloys or on other non acid resisting materials.
STORAGE	Store in tightly closed original container. Keep away from food, drink and animal feeding stuffs. Store away from: Chlorine and Alkalis. Storage: -10 - 35 °C Durability: 36 months.
SAFETY	Please see the enclosed safety data sheet for information about handling and disposal. For professional users only.

INSTRUCTIONS AND DOSAGE

COFFE MACHINE:

Fill the container 2/3 with cold water and add 0.5 dl Lime 374 per L water. Turn on and let it boil. Repeat the treatment in case of heavy lime scale. Rinse the water container thoroughly and boil twice with cold water.

WASHING MACHINE:

Add 2 dl Lime 374 in the soap dispenser in a 4 kg machine and set the empty machine on boil wash. It is recommended to do this procedure once a month.

DISHWASHER:

Empty the water tank an turn of dosing equipment. Fill the machine with clean water and add Lime 374 until a solution of 2.5 % (25 ml per L water) is achieved.

Turn on the machine and let the solution work for approx 15 min. Empty the water tank and check for further deposits. Repeat the procedure if necessary.

At the end, the machine is rinsed thoroughly with clean water and air-dried with the door open.

REMEMBER TO TURN ON THE DOSING EQUIPMENT AGAIN.

PRODUCTDATA

Colour	Colorless.
Physical state	Liquid
Odour	Without odor.
Bulk density	1,05 kg/l
pH Concentrate	< 1,0
pH (Aqueous solution) 5%	~ 2,0

