

Water Polo Goal Malmsten

(1511003)

Assembly Instructions, Maintenance and Warranty











III. Maintenance and Service

To ensure long-lasting and safe use of the equipment, periodical inspections are required:

- Every time before using the equipment:
- · Visually check if there are any parts damaged or missing
- Check if all the devices are installed correctly and secured to prevent tilting/moving
- Every 6 months a detailed check-up of the equipment is required:
 Visual checkup if any deformities, damages, missing or worn out parts (bolts, nuts, net hooks, etc.) have occurred. Tighten all assembly nodes (in order to make sure that all screws and nuts are tightened).

Care and Usage Instruction:

- Only use tools delivered with the goal for periodical tightening of the screws, otherwise the bolts and nuts may corrode.
- After using the product it is required to wash it with tap water and let it dry before placing it in a storage room. Only light detergents like dish soap can be used for cleaning. Alcohol-based detergents might damage the goal.
- It is recommended to dry the goal with paper towels or microfiber cloth after pulling out of the water and rinsing it with tap water.
- It is required for the goal to be stored in a dry area, preferably in a separate, well ventilated area.
- If any atypical signs are noticed (for instance squeaky noises, missing elements, or visual damages) immediately stop further usage of the equipment and report the problem to the manufacturer or its authorized distributor.
- All portable/floating devices must be installed and operated only by designated and trained personnel.

WARNING:

Storage and usage shall be so that no unauthorized person or child can accidently be injured by a falling or tilting goal. Usage in the pool; the goal shall be secured in position by 4 goal lines. In storage; ensure safe locked storage. THIS IS NOT A TOY!





IV. TERMS OF WARRANTY

General Provisions

1.1 M. MALMSTEN AB (the "Manufacturer") provides the limited warranty (the "Warranty") to the purchaser of the Equipment. Warranty is only valid in the facility in which the Equipment was originally installed. The Warranty is valid from the time of the final acceptance of the building or from the date of delivery and to the timeline listed below, under the terms and conditions stated below.

No.	Element	Warranty
1	1511003 Water Polo Goal Malmsten	12 months

- 1.2 The manufacturer warrants the Equipment against defects in material or factory workmanship which is caused by failure of the Equipment within the applicable Warranty Period.
- 1.3 In case of a defect discovered, the purchaser is obtained to immediately (not later than after 7 days) inform the manufacturer or authorized distributor about the problem. The manufacturer or its authorized distributor will answer within 14 days and will propose a way to solve the issue.
- 1.4 The purchaser is obtained to provide information about failures or defects in writing to info@malmsten.com or to a local authorized distributor.
- 1.5 The information about warranty claims should include the serial number (printed on the upper right corner of the crossbar see picture below), description of the issue and date of discovering of the defect. Photographic documentation will be required.
- 1.6 The manufacturer/distributor, once it confirms the existence of a covered defect will (at its sole discretion) repair or replace the defective parts.
- 1.7 Defects or damages that occurred during proper use will be repaired or replaced by the manufacturer or by the authorized distributor.
- 1.8 The warranty covers the costs of investigation, production and shipping. Disassembly of the damaged and installation of the new/repaired part/parts is not covered.

WARNING:

All unauthorized (not provided by the distributor or manufacturer) self-repairs, adjustments or interferences in the equipment can cause irreparable damages and dangerous, life-threatening accidents.





2 Exclusions and Conditions:

- Operations, which shall be made by the user and on his cost, such as maintenance of cleanliness, periodical checkups (as in point 2.1)
- Mechanical and chemical damages caused by improper use and maintenance (i.e. attempts of self-repair; lack of maintenances and inspections; using inadequate cleaning agents, adjustments made by the user)
- Mechanical damages caused by the excessive burden on the equipment
- Damages caused by the user or third party (including acts of vandalism) hang, swing or climb on the equipment
- Consumable parts (like nets, net hooks, etc.)
- Damages caused by operation of the equipment by non-authorized persons
- Installation of the equipment not performed in accordance with the assembly manual
- Damages caused by natural disasters such as floods, fire, wind, lightning or other acts of nature
- Damages caused by usage not in accordance with equipment destination

3 Post-warranty Services

- 3.1 After the warranty expires, it is recommended to order a professional post-warranty service performed by the authorized distributor once every 12 months in order to make sure, that the equipment is in good condition and can be used safely.
- In case of a failure discovered after the time of warranty, the user might inform the manufacturer or it's authorized distributor about the problem in the same way which is described in point 1.4. The manufacturer or distributor will offer a solution to the problem within 7 days. After the claim is accepted, both parties will agree on a suitable term of repairs.



